

D U S T C O N S O L U T I O N S

Collecting and Shipping Dust Sample for Testing



1

Collect representative sample(s)

- **The collection point for your dust sample will depend on what you want to learn from the dust testing.** Samples may be taken from:
 - » Dust Collector or Central Vacuum Receiver, scrapematerial directly from filters if possible
 - » Accumulations on top of equipment, rafters, ledges Raw material or Final Product Storage
 - » Scoop, pour or sweep dust into either an unbreakable plastic jar or double bagged in freezer-style zip-lock bags.
- Clearly mark the jar/bag with a Sample Name.
- Verify the weight of your dust sample is sufficient based on the required qty on the Proposal. Note the required weight of the sample may require a larger volume if it is light/fluffy.
- If grinding/sieving is required, 3x to 4x additional sample will be needed. Check if you will be testing "per protocol."



2

Package the sample(s)

- **Please package the sample jar/bag into a package that may be shipped via UPS or similar means.**
- Within the package, be sure to include MSDS and a copy of the Proposal and/or Purchase Order.
- If MSDS is not available for your material, clearly mark the sample with the type of material and whether it is hazardous.
- Indicate the sample name on the Packaging.



3

Ship the sample(s)

- Please send samples to the address below:
 - Dustcon Solutions, Inc.**
 - 4521 PGA Blvd #116**
 - Palm Beach Gardens, FL 33418 Attn: Timothy Heneks**
- Note the tracking information for your package and supply the tracking number to **customerservice@dustconsolutions.com**
- Indicate the sample name on the Packaging.